

## Table of Contents

### Chapter 1 – The Sampling Plan

---

- 1.1 Introduction**
- 1.2 The Triad Approach**
- 1.3 Site History – Evaluating Existing Data/File Information**
- 1.4 Defining the Physical Environment**
- 1.5 Sample Locations and Numbers**
- 1.6 Sample Methodology and Matrix**
- 1.7 Laboratory Selection**
- 1.8 Electronic Submission of Data for Site Remediation and Waste Management**
  - 1.8.1 General Requirements
  - 1.8.2 Consistency in Data Fields Among Data Tables
  - 1.8.3 Securing Laboratory Services
  - 1.8.4 Geographically Referenced Points
  - 1.8.5 Permit Application and Compliance
- 1.9 Quality Assurance Considerations**
- 1.10 Health and Safety Concerns**
- 1.11 Schedule**

#### References

#### URLs

### Chapter 2 – Quality Assurance

---

- 2.1 Introduction**
  - 2.1.1 Laboratory Certification
  - 2.1.2 Analyze Immediately – Environmental Laboratory Certification
  - 2.1.3 Field and Laboratory Immunoassay Analysis Certification
- 2.2 Data Quality Levels**
  - 2.2.1 Quality Assurance Programs
  - 2.2.2 Field Analytical Methods
- 2.3 Sample Containers**
  - 2.3.1 Reactivity of Container Material With Sample
  - 2.3.2 Volume of the Container
  - 2.3.3 Color of Container
  - 2.3.4 Container Closures
  - 2.3.5 Decontamination of Sample Containers
  - 2.3.6 Chain of Custody
  - 2.3.7 Sample Bottle Storage and Transport
- 2.4 Decontamination Procedures**
  - 2.4.1 Eight-Step Decontamination Procedure For Aqueous and Non-Aqueous Sampling Equipment – Laboratory Only
  - 2.4.2 Three-Step Equipment Decontamination Procedure Non-Aqueous Matrix Only – Laboratory and Field
  - 2.4.3 US Army Cold Regions Research and Engineering Laboratory Decontamination Procedures for Use Primarily on Water Sampling (or Ground-Water Sampling) Equipment – Laboratory and/or Field Exclusively for Organics Including Pesticides

2.4.4 Ultra Clean Sampling Equipment Decontamination – Laboratory or Field

Table 2.1 Ultra Clean Supplies for Water Sampling Device Cleaning

2.4.5 General Decontamination Considerations

2.4.5.1 Decontamination of Pumps

2.4.5.1.1 Purging Only

2.4.5.1.1.1 Submersible

2.4.5.1.1.2 Surface Centrifugal and Diaphragm Pumps

2.4.5.1.2 Sampling

2.4.5.1.2.1 Submersible (Low Flow Purging and Sampling Method)

2.4.5.1.2.2 Bladder Pumps

2.4.5.2 Decontamination of Heavy Equipment

2.4.5.3 Decontamination of Direct Push Equipment

2.4.5.4 Decontamination of Monitor Well Casing and Screen

2.4.5.5 Cleaning Location

2.4.5.6 Disposal of Drill Cuttings

2.4.5.7 Disposal of Installation, Development, Purge, Pump Test and Decontamination Waters

**2.5 Procedures For Quality Assurance and Quality Control (QA/QC)**

2.5.1 Non-Aqueous Matrix

2.5.1.1 Field Blanks

2.5.1.1.1 Description

2.5.1.1.2 Frequency

2.5.1.2 Trip Blanks

2.5.2 Aqueous Matrix

2.5.2.1 Field Blanks

2.5.2.2 Trip Blanks (Field Reagent Blanks)

2.5.2.2.1 Description

2.5.2.2.2 Frequency

2.5.3 Air Matrix

2.5.4 Blank Water Quality

2.5.5 Sample Handling and Holding Times

2.5.5.1 Handling Time

2.5.5.2 Maximum Holding Time

2.5.6 Special Analytical Services (SAS)

2.5.7 Additional QA/QC Samples

2.5.7.1 Duplicate Samples Obtained in the Field (Field Duplicates)

2.5.7.1.1 Aqueous Matrix Duplicates

2.5.7.1.2 Non-Aqueous Matrix Duplicates

2.5.7.2 Splitting Samples with Responsible Parties

2.5.7.3 Background Samples

**2.6 Sample Preservation Requirements**

**References**

**URLs**

**Appendix 2.1 Tables of Analytical Methods**

**Table 2.2 Required Preservation, Container, and Maximum Holding Times for Drinking Water Samples, Except Radiochemical Parameters**

**Table 2.3 Required Preservation, Container, and Maximum Holding Times for Wastewater Samples and Solid/Hazardous Waste Samples (Aqueous Matrices), Except Radiochemical Parameters**

**Table 2.4 Required Preservation, Container and Maximum Holding Times for Radiochemical Measurements in Drinking Water and Wastewater Samples**

**Table 2.5 Required Preservation, Container and Maximum Holding Times for Radiochemical Measurements in Solid/Hazardous Waste Samples (Soils, Liquids, Sediments, and Sludges)**

**Table 2.6 Required Preservation, Container and Maximum Holding Times for Solid/Hazardous Waste Samples (Soils, Liquids, Sediments, Sludges, and Ambient Air)**

**Table 2.7 Required Preservation, Container and Maximum Holding Times From VTSR for CERCLA-CLP Aqueous and Non-Aqueous Samples**

**Footnotes**

**Table 2.8 Analysis of BIOLOGICAL Samples Using NJDEP Methodologies for Freshwater, Estuarine and Marine Samples**

---

**Chapter 3 – Gaining Entry to Inspect Sites For Actual or Suspected Pollution**

---

**3.1 General Rules and Exceptions**

**3.2 Procedure to be Followed to Gain Entry to a Site Where No Emergency Exists**

3.2.1 Initial approach

3.2.2 If voluntary consent is initially refused

3.2.3 If consent cannot be obtained by the DLPS and time is not of the essence

3.2.4 If consent cannot be obtained in response to a letter, or if time is of the essence

**3.3 Procedure to be Followed to Gain Entry to a Site When an Emergency Exists**

**3.4 Statutory Authority to Conduct Searches**

---

**Chapter 4 – Site Entry Activities**

---

**4.1 Introduction**

**4.2 Health and Safety Program Plans**

4.2.1 Organizational Structure

4.2.2 Hazard Analysis and/or Site Risk

4.2.3 Training Requirements for On-Site Personnel

4.2.4 Engineering Controls and Personnel Protection

4.2.5 Medical Surveillance Program

4.2.6 Air Monitoring

4.2.7 Site Control

4.2.8 Decontamination

4.2.9 Emergency Contingency Planning

4.2.10 Confined Space Operations

4.2.11 Other Special Operations

**4.3 General Safety Measures**

4.3.1 Personal Practices

4.3.2 Operations Management

**4.4 Site Entry And Reconnaissance**

4.4.1 Objectives

4.4.2 Preliminary Off-Site Evaluation

4.4.3 Preliminary On-Site Evaluation

Table 4.1 Atmospheric Hazard Guidelines

4.4.4 Other Considerations

**References**

## Chapter 5 – Sampling Equipment

---

### 5.1 Introduction

Table 5.1 Materials of Construction for Ground Water Sampling Equipment

### 5.2 Aqueous And Other Liquid Sampling Equipment

#### 5.2.1 Ground Water Sampling Equipment

##### 5.2.1.1 Bottom Fill Bailer

Figure 5.1 Bottom fill bailer with Teflon® coated stainless leader

Figure 5.2 Teflon® constructed baler with Teflon® ball check valve

##### 5.2.1.2 Peristaltic Pump

Figure 5.3 Geopump™ Peristaltic Pump

##### 5.2.1.3 Bladder Pump

Figure 5.4 Example of a Teflon® constructed bladder pump

##### 5.2.1.4 Variable Speed Submersible Centrifugal Pump

Figure 5.5 Grundfos® Pump

Figure 5.6 Grundfos® Pump being prepared for decontamination

##### 5.2.1.5 Gear Pump

Figure 5.7 Fultz Pump

Figure 5.8 Gear Pump

##### 5.2.1.6 Progressing Cavity Pump

Figure 5.9 Progressive Cavity Pump

##### 5.2.1.7 Reciprocating Piston Pump

Figure 5.10 Reciprocating Piston Pump

Figure 5.11 Bennett Pump

##### 5.2.1.8 Inertial Pump

Figure 5.12 Inertial Pump (Waterra)

Figure 5.13 Two styles of foot check valves offered by Geoprobe®

##### 5.2.1.9 Syringe Sampler

Figure 5.14 Syringe Sampler

##### 5.2.1.10 Suction-lift Pumps

##### 5.2.1.11 Passive Diffusion Bag Samplers (PDBs)

###### 5.2.1.11.1 Deployed In Monitor Wells

Figure 5.15 Eon PDB Sampler with accessories

###### 5.2.1.11.2 Deployed in Lake, Stream, River or Estuarine Sediment

Figure 5.16 PDB for Sediments

##### 5.2.1.12 Direct Push Technology

##### 5.2.1.13 Packers

#### 5.2.2 Wastewater Sampling Equipment

##### 5.2.2.1 Manual Sampling

##### 5.2.2.2 Automatic Sampling

Figure 5.17 ISCO® Sampler for single bottle collection

Figure 5.18 ISCO® Sampler for multiple bottle collection

#### 5.2.3 Surface Water and Liquid Sampling Equipment

##### 5.2.3.1 Laboratory Cleaned Sample Bottle

##### 5.2.3.2 Pond Sampler

Figure 5.19 Pond Sampler

Figure 5.20 Fabricated Pond Sampler

##### 5.2.3.3 Weighted Bottle Sampler

Figure 5.21 US WBH-96 Weighted Bottle Sampler

- 5.2.3.4 Wheaton Dip Sampler  
Figure 5.22 Wheaton Dip Sampler
- 5.2.3.5 Kemmerer Depth Sampler  
Figure 5.23 Kemmerer Depth Sampler
- 5.2.3.6 Van Dorn Sampler  
Figure 5.24 Van Dorn Sampler
- 5.2.3.7 Other Water Bottle Samplers
- 5.2.3.8 VOC Sampler  
Figure 5.25 VOC Sampler
- 5.2.3.9 Double Check Valve Bailer  
Figure 5.26 Double Check Valve Bailer
- 5.2.3.10 Bacon Bomb Sampler  
Figure 5.27 Bacon Bomb Sampler
- 5.2.3.11 Continuous Water-Quality Monitors
- 5.2.3.12 Churn Splitter
- 5.2.3.13 Sample Collection and Preservation Chamber
- 5.2.4 Containerized Liquid Sampling Equipment
  - 5.2.4.1 Coliwasa  
Figure 5.28 Coliwasa
  - 5.2.4.2 Open Tube Thief Sampler  
Figure 5.29 Open Tube Thief Sampler
  - 5.2.4.3 Stratified Thief Sampler  
Figure 5.30 Stratified Thief Sampler

### **5.3 Non-aqueous Sampling Equipment**

- 5.3.1 Soil Sampling Equipment
  - 5.3.1.2 Scoop/Trowel  
Figure 5.31 Scoop/Trowel
  - 5.3.1.2 Bucket Auger  
Figure 5.32 Bucket Auger
  - 5.3.1.3 Soil Coring Device  
Figure 5.33 Soil Coring Device
  - 5.3.1.4 Split Spoon Sampler  
Figure 5.34 Split Spoon Sampler
  - 5.3.1.5 Shelby Tube Sampler
  - 5.3.1.6 En Core<sup>®</sup> Sampler  
Figure 5.35 En Core<sup>®</sup> Sampler with T Handle
  - 5.3.1.7 Power Auger
  - 5.3.1.8 Direct Push Technology
- 5.3.2 Sediment and Sludge Sampling Equipment
  - 5.3.2.1 Benthic Grab Samplers
    - 5.3.2.1.1 Ponar Dredge  
Figure 5.36 Ponar Dredge
    - 5.3.2.1.2 Ekman Grab Sampler  
Figure 5.37 Ekman Grab Sampler
    - 5.3.2.1.3 Box Corer  
Figure 5.38 Box Corer
    - 5.3.2.1.4 Shipek<sup>®</sup>  
Figure 5.39 Shipek<sup>®</sup> Grab Sampler
    - 5.3.2.1.5 Van Veen

	Figure 5.40 Van Veen Grab
5.3.2.1.6	Petersen Grab
	Figure 5.41 Petersen Grab
5.3.2.2	Sediment Core Samplers
5.3.2.2.1	Hand Corer
	Figure 5.42 Hand Corer
5.3.2.2.2	Russian Peat Borer
	Figure 5.43 Russian Peat Borer
5.3.2.2.3	Split Core Sampler
	Figure 5.44 Split Core Sampler
5.3.2.2.4	Gravity Corer
	Figure 5.45 Gravity Corers
5.3.2.2.5	Vibracorer
	Figure 5.46 Vibracorer
5.3.2.2.6	Sediment Sieve
	Table 5.2 General Characteristics of Selected Grab and Core Sampler
5.3.2.3	Sludge Samplers
5.3.2.3.1	Lidded Sludge/Water Sampler
	Figure 5.47 Lidded Sludge/Water Sampler
5.3.2.3.2	Liquid Grab Sampler
	Figure 5.48 Liquid Grab Sampler
5.3.2.3.3	Swing Jar Sampler
	Figure 5.49 Swing Jar Sampler
5.3.2.3.4	Sludge Judge
	Figure 5.50 Sludge Judge
5.3.3	Containerized Solids and Waste Pile Sampling Equipment
5.3.3.1	Grain Sampler
	Figure 5.51 Grain Sampler
5.3.3.2	Waste Pile Sampler
	Figure 5.52 Waste Pile Sampler
5.3.3.3	Sampling Trier
	Figure 5.53 Sampling Trier
	Table 5.3 Samplers Recommended for Various Types of Waste

## **References**

### **USGS Links of Interest**

### **USEPA Links of Interest**

### **Other URLs of Interest**

## **Appendix 5.1 – Sample Collection And Preservation Chamber**

## **Chapter 6 – Sample Collection**

---

### **6.1 General Information Applicable To All Sampling Events**

- 6.1.1 Preparation
- 6.1.2 Type of Samples
  - 6.1.2.1 Environmental and Waste Samples
  - 6.1.2.2 Grab vs. Composite
- 6.1.3 Laboratory Procurement
- 6.1.4 Quality Assurance Samples
- 6.1.5 Quality Assurance Project Plans

6.1.6 Assuring Health and Safety

6.1.7 Post Sampling Activities

## **6.2 Soil Sampling**

6.2.1 Selection of Sampling Equipment

6.2.2 Equipment Preparation

6.2.3 Soil Logs

6.2.3.1 Wentworth Scale

Table 6.1 Wentworth Scale as Modified from Driscoll, 1986, and Folk, 1975.

6.2.3.2 Unified Soil Classification System (USCS)

Table 6.2 Unified Soil Classification System; from American Society for Testing and Materials, 1985

Table 6.3. Unified Soil Classification System (USCS)

6.2.3.3 Burmister System

Table 6.4 Burmister Soil Classification Naming System (source: Dunn Geoscience Corporation)

Table 6.5 Burmister Soil Classification System Coarse-Grained Soils, Gradation of Components

Table 6.6 Burmister Soil Classification System Fine-Grained Soils, Plasticity of Components

Table 6.7 Burmister Soil Classification System, Components and Fractions, Modified from Burmister, 1950

6.2.3.4 U.S. Comprehensive Soil Classification System

Table 6.8 Textural Descriptions for USDA System

6.2.3.5 Comparison of the Soil Classification Systems

6.2.4 Field Log Books

Table 6.9 Comparison of the Soil Classification Systems compiled from various sources  
Boring Log

6.2.5 Determination of Soil Sample Location

6.2.5.1 Surface Soil Selection

6.2.5.2 Subsurface Soil Selection

6.2.6 Field Screening Soil Samples

6.2.7 VOCs Sample Collection for Soils

6.2.7.1 VOC Soil Sample Depth Selection

6.2.7.2 VOC Soil Sample Collection Devices - Small Diameter Core Samplers

6.2.7.2.1 Disposable Syringe

6.2.7.2.2 Easy-Draw Syringe and Power-Stop Handle

6.2.7.2.3 Purge and Trap Soil Sampler®

6.2.7.2.4 En Core® Sampler

6.2.7.3 VOC Soil Sample Collection Technique

6.2.7.4 VOC Soil Sample Preservation Methods

6.2.7.4.1 Closed-System Vials, No Chemical Preservation

6.2.7.4.2 Closed-System Vials, No Chemical Preservation with Organic Free Water (OFW)

6.2.7.4.3 Small Diameter Core Sampler for Storage and Transport (e.g., En Core® Sampler)

6.2.7.4.4 Closed-System Vials, Chemical Preservation – Sodium Bisulfate

6.2.7.4.5 Closed-System Vials, Chemical Preservation – Methanol

6.2.7.4.6 Glass Containers, No Chemical Preservation, No Headpace

6.2.7.5 Sample Aliquot for Moisture Determination and Sample Screening

6.2.7.6 Commercial Equipment Suppliers

Table 6.10 Discrete Soil Sampler Suppliers

6.2.8 Non-VOC Sample Collection for Soils

6.2.9 Sampling Alternatives for Situational and Matrix Variations

- 6.2.9.1 Sampling Hard or Cemented Material
- 6.2.9.2 Sampling a Mixture of Fines and Gravel
- 6.2.9.3 Sampling Dry Non-Cohesive Material
- 6.2.9.4 Sampling Sediments
- 6.2.9.5 Sampling Oil Waste, Tars and Other Waste Material
- 6.2.9.6 Sampling from Test Pits

**6.3 Rock Core Sample Collection**

6.3.1 Coring Methods

- 6.3.1.1 Drill String Coring
- 6.3.1.2 Wireline Coring

6.3.2 Coring Tools

6.3.2.1 Tube-Type Coring Tools

Figure 6.1 Double tube coring tool. Anderson, 1975, printed with permission.

Figure 6.2 Impregnated diamond bit. Acker, 1974, printed with permission.

6.3.2.2 Sidewall Coring Tools

6.3.2.3 Oriented Coring Tools

6.3.3 Coring Procedures

6.3.4 Rock Core Logging

6.3.5 Rock Core Storage

6.3.6 Special Tests and Analyses of Rock Cores

Table 6.11 Rock Coring Requirements

**6.4 Direct Push Technology**

**6.5 Sampling Containerized Material**

6.5.1 Drums, Bags, Sacks, Fiberdrums and Similar Small Containers

- 6.5.1.1 Containerized Solids
- 6.5.1.2 Containerized Liquids

6.5.2 Tanks, Vacuum Trucks, Process Vessels and Similar Large Containers

6.5.3 Transformers

**6.6 Waste Pile Sampling**

6.6.1 Considerations for the Sampling Plan

- 6.6.1.1 Shape and Size
- 6.6.1.2 Characteristics of the Material
  - 6.6.1.2.1 Type of Material
  - 6.6.1.2.2 Chemical Stability
  - 6.6.1.2.3 Particle Size
  - 6.6.1.2.4 Compactness/Structure of Material
- 6.6.1.3 Purpose of Sampling

6.6.2 Sampling Procedures

- 6.6.2.1 Surface
- 6.6.2.2 At Depth

6.6.3 Required Analytes and Frequency

- 6.6.3.1 Waste Classification
- 6.6.3.2 Quality Assurance
- 6.6.3.3 Characterization

**6.7 Surficial Sampling**

- 6.7.1 Wipe Samples
- 6.7.2 Chip Samples

6.7.3 Sweep Samples

6.7.4 Rinsate Samples

## **6.8 Surface Water And Sediment Sampling**

6.8.1 General Considerations and Requirements for NJDEP Programs

6.8.1.1 Health and Safety Considerations

6.8.1.2 Physical Characteristics and Water Quality Measurements for Ambient Monitoring

6.8.1.3 Sample Number and Location

6.8.1.4 Sampling Sequence

6.8.1.5 Surface Water Flow Conditions

6.8.1.6 Tidal Influences

6.8.1.7 Equipment Selection

6.8.1.7.1 Aqueous

6.8.1.7.2 Non-Aqueous

6.8.1.8 Considerations for Wastewater Point Source Sampling

6.8.2 Freshwater and Biological Monitoring Program

6.8.2.1 Sampling Objectives

6.8.2.2 Aqueous Samples

6.8.2.2.1 Stream/Flowing Water

6.8.2.2.2 Composite Sampling

6.8.2.2.3 Grab Sampling

6.8.2.2.4 Point Sampling

6.8.2.2.5 Lake/Standing Water Sampling

6.8.2.2.6 Estuarine and Marine Water Sampling

6.8.2.2.7 Bacteriology

6.8.2.2.8 Trace Element Sampling

6.8.2.3 Non-Aqueous Samples

6.8.2.3.1 Sediments

6.8.2.3.1.1 Onshore

6.8.2.3.1.2 Offshore

6.8.2.3.1.3 General Procedures

6.8.2.3.2 Sludge

6.8.2.4 Flow Measurements

6.8.2.4.1 Open-Channel Flow Measurement

6.8.2.4.2 Open-Channel Flow Meters

6.8.2.4.2.1 Palmer-Bowlus Flumes

6.8.2.4.2.2 Parshall Flumes

6.8.2.4.3 Weirs

6.8.2.4.3.1 V-Notch Weirs

6.8.2.4.3.2 Rectangular Weirs

6.8.2.4.3.3 H-Type Flumes

6.8.2.4.4 Instrumentation for Open-Channel Flow

6.8.2.4.5 Closed-Pipe Flow Metering Systems

6.8.2.4.6 Types of Meters, Methods and Systems

6.8.2.4.6.1 Electromagnetic Flow Meters

6.8.2.4.6.2 Turbine Meters and Propeller Meters

6.8.2.4.6.3 Rotating Element Current Meters

Figure 6.3 Propeller Current Meter

Figure 6.4 Price Current Meter

6.8.2.4.6.4 Ultrasonic Meters

- 6.8.2.4.6.5 Pitot Tube Meters
- 6.8.2.4.6.6 Differential Pressure Systems
- 6.8.2.4.6.7 Velocity Modified Flow Meters
- 6.8.2.4.6.8 Floats
- 6.8.2.4.6.9 Salt Velocity Method
- 6.8.2.4.6.10 Color Velocity Method
- 6.8.2.4.6.11 Discharge
- 6.8.2.4.7 Miscellaneous Flow Measurement Methods
  - 6.8.2.4.7.1 Water Meters
  - 6.8.2.4.7.2 Measure Level Changes in Tank

Figure 6.5 Stationary Volume of Liquid in Horizontal Cylinders

### 6.8.3 Site Remediation and Waste Management Program

#### 6.8.3.1 Sampling Objectives

Table 6.12 Comparison of Various Methods to Obtain Mean Velocity

##### 6.8.3.1.1 Site-Related Sample Locations

##### 6.8.3.1.2 Reference Sample Location

#### 6.8.3.2 Aqueous Samples

##### 6.8.3.2.1 Flowing Non-Tidal Water Bodies

##### 6.8.3.2.2 Standing Water Bodies

##### 6.8.3.2.3 Tidal Water Bodies

##### 6.8.3.2.4 Determination of Contaminated Ground Water Discharge Points

#### 6.8.3.3 Non-Aqueous Samples

##### 6.8.3.3.1 General

##### 6.8.3.3.2 Flowing Non-Tidal Water Bodies

##### 6.8.3.3.3 Standing Water Bodies

##### 6.8.3.3.4 Tidal Water Bodies

#### 6.8.3.4 Use of Passive Diffusion Bag Samplers

## 6.9 Ground Water Sampling Procedures

### 6.9.1 Scope

### 6.9.2 Means of Sample Collection

#### 6.9.2.1 Temporary Well Points and Direct Push Technology

#### 6.9.2.2 Low-Flow Purging and Sampling

##### 6.9.2.2.1 Method Summary and Application

##### 6.9.2.2.2 Introduction

Low Flow Sampling Data Sheet

Field Instrumentation and Calibration Data Sheet

Monitor Well Information in Support of Pump Intake Depth Placement

##### 6.9.2.2.3 Low Flow Policy

##### 6.9.2.2.4 Laboratory Certification (N.J.A.C. 7:18)

##### 6.9.2.2.5 Specific LFPS Considerations

###### 6.9.2.2.5.1 Pump Intake Location

###### 6.9.2.2.5.2 Water Quality Indicator Parameters (WQIPs)

###### 6.9.2.2.5.3 Purge Volume vs. Stabilization Time

###### 6.9.2.2.5.4 Tubing

###### 6.9.2.2.5.5 Flow-Through Cell

Figure 6.6 Illustration of Flow Cell with stand

###### 6.9.2.2.5.6 Pump Selection

###### 6.9.2.2.5.7 Plumbing Fittings

Figure 6.7 Closeup of Needle Valve

6.9.2.2.5.8	Calibration of Probes	
6.9.2.2.5.9	Water Level Measurements	
6.9.2.2.5.10	Pump Installation	
6.9.2.2.5.11	Purge Rates	
6.9.2.2.5.12	Sampling	
6.9.2.2.5.13	Pump Decontamination	
	Figure 6.8 Grundfos® Pump being prepared for decontamination	
6.9.2.2.5.14	Field Blank Collection	
6.9.2.2.6	Tips	
6.9.2.2.6.1	Temperature Measurement and Submersible Pumps	
6.9.2.2.6.2	Control of Pump Speed	
6.9.2.2.6.3	pH	
6.9.2.2.6.4	Temperature of Calibration Solutions	
6.9.2.3	Low-flow Purging and Sampling for Low-Yielding Wells	
6.9.2.4	Volume-Averaged Purging and Sample Collection	
6.9.2.5	Point Source (No-Purge) Sampling	
6.9.2.5.1	Passive Diffusion Bag Samplers (PDBS)	
6.9.2.5.1.1	Introduction	
6.9.2.5.1.2	Limitations And Concerns	
6.9.2.5.1.3	Theory	
6.9.2.5.1.4	PDBS Construction	
6.9.2.5.1.5	Contaminant Detection Capabilities	
	Table 6-13 Passive Diffusion Bag Samplers (PDBS)	
6.9.2.5.1.6	Well Construction Considerations	
6.9.2.5.1.7	Contaminant Stratification/Multiple Sampler Deployment	
6.9.2.5.1.8	Vertical Flow Within the Well	
6.9.2.5.1.9	Comparison of PDBS Results with Conventional Sampling Methods	
6.9.2.5.1.10	Use of PDBS in Sentinel Wells	
6.9.2.5.1.11	Procedures for PDBS Use (Deployment/Retrieval)	
6.9.2.5.1.11.1	Weights and Deployment Lines	
6.9.2.5.1.11.2	Measuring and Attaching the PDBS to the Deployment Line	
6.9.2.5.1.11.3	Equilibration Time	
6.9.2.5.1.11.4	Sample Retrieval	
6.9.2.5.1.11.5	Quality Assurance/Quality Control Samples	
6.9.2.5.1.11.5.1	Blanks for Lab filled PDBS	
6.9.2.5.1.11.5.2	Blanks for Field Filled PDBS	
6.9.2.5.1.12	Data Reporting Requirements	
	NJDEP Checklist for the Submission of Sampling Data for Passive Diffusion Bag Samplers (PDBS)	
6.9.3	Sampling Private Homeowner Wells (a.k.a. Public Non-Community/Non-Public/Domestic Wells)	
6.9.4	Sampling Point of Entry Treatment (POET) Systems	
6.9.5	Sampling Industrial Wells	
6.9.6	Sampling Municipal and Industrial Wastewater	
	Table 6.14 Suggested Biochemical Oxygen Demand Dilutions	
6.9.7	Public Community Water Systems	
6.9.7.1	Source Sample (Raw water)	
6.9.7.1.1	Ground Water	
6.9.7.1.2	Surface Water	
6.9.7.2	Plant Delivered Sample (Finished Water)	

- 6.9.7.3 Point of Entry Sample
- 6.9.7.4 System Sample
- 6.9.8 Ground Water-Level Measurements
  - 6.9.8.1 Steel Tapes
  - 6.9.8.2 Electronic Ground Water-Level Indicators
  - 6.9.8.3 Helpful Hints
  - 6.9.8.4 Ground Water Level and Non-Aqueous Phase Liquid (NAPL) Measurements
    - 6.9.8.4.1 Clear Bailer
    - 6.9.8.4.2 Interface Probes
- 6.9.9 New Well Construction and Stabilization
  - 6.9.9.1 Well Development
    - Figure 6.9 Sand Bridges
  - 6.9.9.2 Other Considerations
- 6.9.10 Filtering Ground Water Samples
  - 6.9.10.1 Total Metals Sampling
  - 6.9.10.2 Trace Metals Sampling
  - 6.9.10.3 Dissolved Metals Sampling
  - 6.9.10.4 Filtering Procedures for Dissolved Metals Analysis
- 6.9.11 Sampling for Light, Non-Aqueous Phase Liquids (LNAPLS)
- 6.9.12 Sampling for Dense, Non-Aqueous Phase Liquids (DNAPLs)

## **6.10 Biological Sampling Procedures**

- 6.10.1 Phytoplankton Sampling
  - 6.10.1.1 Sample Site Location
  - 6.10.1.2 Sampling Depth
  - 6.10.1.3 Sampling Procedure
- 6.10.2 Zooplankton Sampling
  - 6.10.2.1 Sample Site Location
  - 6.10.2.2 Sample Depth
  - 6.10.2.3 Sampling Procedure
- 6.10.3 Macrophyte Sampling
- 6.10.4 Macroinvertebrates
  - 6.10.4.1 Hester-Dendy Artificial Substrates
    - 6.10.4.1.1 Sampler Placement
    - 6.10.4.1.2 Sampler Retrieval
  - 6.10.4.2 Surber or Square Foot Bottom Sampler
    - 6.10.4.2.1 Sampler Placement
    - 6.10.4.2.2 Sampler Retrieval
- 6.10.5 Grab Samplers
- 6.10.6 Periphyton Sampling
  - 6.10.6.1 Artificial Substrates
    - 6.10.6.1.1 Sampler Placement
    - 6.10.6.1.2 Sampler Retrieval
  - 6.10.6.2 Natural Substrates
- 6.10.7 Rapid Bioassessment (RBP) Techniques\*
  - 6.10.7.1 Benthic Macroinvertebrates
  - 6.10.7.2 Single Habitat Sampling
  - 6.10.7.3 Multi-habitat Sampling
  - 6.10.7.4 Periphyton

## **6.11 Toxicological Sampling (Toxicity Test or Bioassay)**

6.11.1 Dilution Water Sample Collection and Handling:

6.11.2 Effluent Samples Shall be Collected and Handled in the Following Manner.

## **Appendix 6.1 Monitor Well Construction and Installation**

### **A.6.1.1 Introduction**

### **A.6.1.2 Conventional Well Drilling Methods**

A.6.1.2.1 Hollow-Stem Augers (HSAs)

A.6.1.2.2 Rotary Drilling

A.6.1.2.3 Drilling Fluids

### **A.6.1.3 Specialized Drilling Methods**

A.6.1.3.1 Sonic Drilling

A.6.1.3.2 ODEX® Method  
Figure 6.10 ODEX® System

A.6.1.3.3 Direct-Push Drilling

### **A.6.1.4 Monitor Well Design And Construction Considerations**

A.6.1.4.1 Well Diameter

A.6.1.4.2 Well Construction Materials

A.6.1.4.3 Screen Length

A.6.1.4.4 Screen Slot Size and Filter Pack Materials

A.6.1.4.5 Grouting Materials

A.6.1.4.6 Well Depth

A.6.1.4.7 Multi-Screened Wells

A.6.1.4.8 Pre-Packed Well Screens

A.6.1.4.9 Horizontal Wells

A.6.1.4.10 Wells Used to Investigate LNAPL and DNAPL

A.6.1.4.11 Lysimeters

### **A.6.1.5 Miscellaneous Well Construction Considerations**

A.6.1.5.1 Well Development

A.6.1.5.2 Maintenance of Wells

A.6.1.5.3 Well Decommissioning Requirements

A.6.1.5.4 Flush Mount Wells

Figure 6.11 Typical Flush-Mount Completion

A.6.1.5.5 Subsurface and Overhead Utilities

## **Appendix 6.2 NJDEP Monitor Well Specifications for Bedrock, Unconsolidated and Confined Aquifers**

### **A.6.2.1 Monitoring Well Requirements For Bedrock Formation**

Figure 6.12 Bedrock Formation Well

### **A.6.2.2 Monitor Well Requirements For Unconsolidated Aquifers**

Figure 6.13 Unconsolidated Aquifer Well

### **A.6.2.3 Monitor Well Requirements For Confined Unconsolidated Aquifers**

Figure 6.14 Confined Unconsolidated Aquifer Well

## **References**

**USGS Links of Interest**

**USEPA Links of Interest**

**Other URLs of Interest**

**Soil Science**

**Soil Classification**

**Sediments**

**Manufacturers/Vendors of Environmental Sampling Equipment**

**General**

**Chapter 7 – Field Analysis**

---

**7.1 Introduction**

**7.2 Application of Field Analytical Methods**

**7.3 Field Analytical Techniques**

**7.4 Specific Advantages of Field Analysis**

**7.5 Selection of a Field Analysis Method**

**7.6 Factors To Be Considered For Field Analyses**

**7.7 Role of Field Screening/Analytical Methods According to the NJDEP Technical Requirements For Site Remediation, N.J.A.C. 7:26E**

**7.8 Regulatory Initiative For Development of Field Analyses**

**7.9 Choosing Appropriate Field Analytical Methods For Contaminant Investigation**

7.9.1 Considerations Prior To Researching Field Analytical Methods

7.9.1.1 Matrix Effects

7.9.1.2 Analyte(s) of Concern

7.9.1.3 Interfering Constituents

7.9.1.4 Limitations

7.9.1.5 Physical Conditions

7.9.2 Searching the Websites

7.9.2.1 FATE

7.9.2.2 EPAREACHIT

7.9.2.3 FRTR

7.9.2.4 CLU-IN

7.9.3 Listing Limitations and Interferences for Selected Field Analytical Methods

7.9.3.1 Matrix Effects

7.9.3.2 Analytes

7.9.3.3 Interfering Constituents

7.9.3.4 Limitations

7.9.3.5 Physical Conditions

**7.10 Quality Assurance Project Plan (QAPP) For Implementation of Field Analytical Methods**

**7.11 Quality Assurance Requirements**

7.11.1 Preliminary or Field Screening Data (Data Quality Level 1)

7.11.2 Effective Data or Field Analysis Data (Data Quality Level 2)

7.11.3 Meticulous or Definitive Data (Data Quality Level 3)

7.11.4 “State-of-the-Art” Data

**7.12 Field Data Deliverables Format**

7.12.1 Field-Screening Data – QA/QC Requirements

7.12.2 Effective Data or Field Analysis Data – QA/QC Requirements

Table 7.1 Overview of Data Quality Classifications

**7.13 Data Management Plan**

**References/Resources**

**Glossary**

## **Chapter 8 – Geophysical Techniques**

---

### **8.1 Introduction**

### **8.2 Ground Penetrating Radar**

- 8.2.1 Fundamentals
- 8.2.2 Advantages
- 8.2.3 Limitations
- 8.2.4 Instrumentation
- 8.2.5 Survey Design, Procedure and Quality Assurance
- 8.2.6 Data Reduction and Interpretation
- 8.2.7 Presentation of Results

### **8.3 Magnetics**

- 8.3.1 Fundamentals
- 8.3.2 Advantages
- 8.3.3 Limitations
- 8.3.4 Instrumentation
- 8.3.5 Survey Design, Procedure and Quality Assurance
- 8.3.6 Data Reduction and Interpretation
- 8.3.7 Presentation of Results

### **8.4 Gravity**

- 8.4.1 Fundamentals
- 8.4.2 Advantages
- 8.4.3 Limitations
- 8.4.4 Survey Design, Procedure and Quality Assurance
- 8.4.5 Data Reduction and Interpretation
- 8.4.6 Presentation of Results

### **8.5 Electrical Resistivity**

- 8.5.1 Fundamentals
- 8.5.2 Advantages
- 8.5.3 Limitations
- 8.5.4 Instrumentation
- 8.5.5 Survey Design, Procedure and Quality Assurance
- 8.5.6 Sounding Mode
- 8.5.7 Profiling Mode
  - Figure 8.1 Common Arrays
- 8.5.8 Profiling-Sounding Mode
- 8.5.9 Resistivity Data Reduction and Interpretation
- 8.5.10 Presentation of Results
  - 8.5.10.1 Sounding Mode
  - 8.5.10.2 Profiling Mode
  - 8.5.10.3 Profiling-Sounding Mode

### **8.6 Induced Polarization**

- 8.6.1 Fundamentals
- 8.6.2 Advantages
- 8.6.3 Limitations
- 8.6.4 Instrumentation
- 8.6.5 Survey Design, Procedure and Quality Assurance
- 8.6.6 Sounding Mode
- 8.6.7 Profiling Mode

- 8.6.8 Profiling-Sounding Mode
- 8.6.9 Data Reduction and Interpretation
- 8.6.10 Presentation of Results

## **8.7 Electromagnetics**

- 8.7.1 Fundamentals
- 8.7.2 Advantages
- 8.7.3 Limitations
- 8.7.4 Instrumentation
- 8.7.5 Survey Design, Procedure and Quality Assurance
- 8.7.6 Data Reduction and Interpretation
- 8.7.7 Presentation of Results

## **8.8 Very-low Frequency (VLF) Electromagnetics**

- 8.8.1 Fundamentals
- 8.8.2 Advantages
- 8.8.3 Limitations
- 8.8.4 Instrumentation
- 8.8.5 Survey Design, Procedure and Quality Assurance
- 8.8.6 Data Reduction and Interpretation
- 8.8.7 Presentation of Results

## **8.9 Seismic**

- 8.9.1 Fundamentals
- 8.9.2 Instrumentation
- 8.9.3 The Seismic Refraction Method
  - Figure 8.2 Seismic Refraction
  - 8.9.3.1 Seismic Refraction Advantages
  - 8.9.3.2 Seismic Refraction Limitations
  - 8.9.3.3 Seismic Refraction Survey Design, Procedure and Quality Assurance
    - Figure 8.3 Observer's Log
  - 8.9.3.4 Seismic Refraction Data Reduction and Interpretation
  - 8.9.3.5 Seismic Refraction Presentation of Results
- 8.9.4 The Seismic Reflection Method
  - Figure 8.4 Seismic Reflection
  - 8.9.4.1 Seismic Reflection Advantages
  - 8.9.4.2 Seismic Reflection Limitations
  - 8.9.4.3 Seismic Reflection Survey Design, Procedure, And Quality Assurance
  - 8.9.4.4 Seismic Reflection Data Reduction and Interpretation
  - 8.9.4.5 Seismic Reflection Presentation of Results

## **8.10 Borehole Geophysical Methods**

- 8.10.1 Introduction
- 8.10.2 Advantages
- 8.10.3 Limitations
- 8.10.4 Types of Borehole Tools
  - 8.10.4.1 Gamma Ray and Self Potential (SP) Devices
  - 8.10.4.2 Electrical Resistivity and Induction Devices
    - Figure 8.5 Lateral Resistivity Sonde
    - Figure 8.6 Normal Resistivity Sonde
    - Figure 8.7 High Frequency Electromagnetic Energy
  - 8.10.4.3 Porosity/Density Devices
    - Figure 8.8 Basic Sonic System

- 8.10.4.4 Mechanical Devices
- 8.10.4.5 Acoustic, Radar and Optical Devices
  - Figure 8.9 Magnetically oriented, acoustic-amplitude image of borehole wall generated from an acoustic televiewer.
  - Figure 8.10 “Virtual core” wrapped (left) and unwrapped (right) images of a bedrock fracture at a depth of 29.4 meters collected with a digital television camera.
- 8.10.5 Quality Assurance
- 8.10.6 Presentation of Results

## References

### URLs for Surface and Borehole Geophysical Methods

## Chapter 9 – Soil Gas Surveys

---

### 9.1 Introduction

### 9.2 Theory

### 9.3 Soil Gas Generation and Movement

- 9.3.1 Biological Decomposition
- 9.3.2 Chemical Decomposition
- 9.3.3 Physical Decomposition
- 9.3.4 Transport Mechanisms
  - 9.3.4.1 Molecular Effusion
  - 9.3.4.2 Molecular Diffusion
  - 9.3.4.3 Convection

### 9.4 Site Specific Characteristics

- 9.4.1 Chemical and Physical Properties of the Contaminant
  - 9.4.1.1 Concentration
    - Table 9.1 Compounds Found in Municipal Solid Waste Landfills
    - Table 9.2 Trace Compounds Found in Municipal Solid Waste Landfills
  - 9.4.1.2 Partitioning
    - Figure 9.1 Phase Relationships for VOCs
  - 9.4.1.3 Vapor Pressure
  - 9.4.1.4 Microbial Degradation
    - Figure 9.2 Transformations of Chlorinated Aliphatic Hydrocarbons
- 9.4.2 Geologic Factors
  - 9.4.2.1 Soil Permeability
  - 9.4.2.2 Thickness of the Unsaturated Zone
  - 9.4.2.3 Barriers and Conductive Zones
    - Figure 9.3A Homogenous Soils in the Vadose Zone
    - Figure 9.3B Impermeable Clay Subsurface Layer
    - Figure 9.3C Impermeable Surface Layer
    - Figure 9.3D Zone of High Microbial Activity
    - Figure 9.3E Source of VOCs in the Vadose Zone
- 9.4.3 Hydrologic and Hydrogeologic Properties
  - 9.4.3.1 Water Table Oscillations
  - 9.4.3.2 Background Water Quality
  - 9.4.3.3 Rainfall, Barometric Pressure and Wind

### 9.5 Investigation Sampling Designs

- 9.5.1 Grids
  - Figure 9.4 Site Monitoring Network Grid Sampling

9.5.2 Transect Lines  
Figure 9.5 Site Monitoring Network Transect Lines

9.5.3 Biased

9.5.4 Random

9.5.5 Combined

9.5.6 Vertical Profiling

9.5.7 Sample Spacing

9.5.8 Sampling Frequency

## **9.6 Health And Safety**

9.6.1 Underground Utilities

9.6.2 License Requirements

Table 9.3 License Requirement

## **9.7 Active Sample Collection Methodologies**

9.7.1 Ground Probes

Figure 9.6 Passive Placed Probe

Figure 9.7 Drive Ground Probe

Figure 9.8 Ground Probes Ambient Air Short Circuiting

9.7.2 Permanent Soil Gas Probes

Figure 9.9 Soil Gas Sampling Probes

Figure 9.10 Soil Gas Well Schematic

Figure 9.11 Ball Valve for Soil Gas Well

Figure 9.12 Comparison of Multi-Depth Soil Gas Well Designs

9.7.3 Materials of Construction

9.7.4 Purge Rates and Volume

Table 9-4. Purge Volumes for Select Tubing Sizes

Figure 9.13A Purge pump with flow control and vacuum gauge

Figure 9.13B Purge pump with DRI inline

Figure 9.13C Purge pump with syringe adapter

9.7.5 Short Circuiting

9.7.6 Pressure Measurements

Figure 9.14 Soil Gas Pressure vs. Barometric Pressure

## **9.8 Passive Sample Collection Methodologies**

9.8.1 Sorbents

Figure 9.15 Passive sorbent sampler

9.8.1.1 Gore-Sorber® Passive Sampler

9.8.1.2 Quadrel Emflux® Soil Gas Sampler

9.8.1.3 Sample Depths

9.8.1.4 Sample Spacing

9.8.1.5 Sample Exposure Time

9.8.1.6 Multiple Surveys

9.8.1.7 Data Interpretation

9.8.2 The Emission Isolation Flux Chamber

Figure 9.16 Surface flux chamber

## **9.9 Soil Gas Sample Containers**

Figure 9.17 Air sampling equipment

9.9.1 Gas Sample Bags

9.9.2 Glass Bulbs

9.9.3 Syringes

9.9.4 Stainless Steel Canisters

9.9.5 Sorbents

## **9.10 Analytical Methodologies**

9.10.1 Detector Tubes

9.10.2 Direct Reading Instruments (DRI)

9.10.3 Portable Gas Chromatographs (G.C.)

9.10.4 GC/Mass Spectroscopy (GC/MS)

## **9.11 Quality Assurance/Quality Control**

9.11.1 Adhere to Sampling Procedures

9.11.2 Equipment Blanks

9.11.3 Trip Blanks

9.11.4 Background Measurements

9.11.5 Duplicates

9.11.6 Decontamination

9.11.7 Leak Checks

9.11.8 Equipment Calibration

9.11.9 Limitations of the Analytical Methodology

## **9.12 Soil Gas Data Interpretation**

## **9.13 Data Reporting**

## **Soil Gas Probe Monitoring Record**

## **References**

## **Chapter 10 – Documentation**

---

### **10.1 Introduction**

### **10.2 Field Log Books**

### **10.3 Documenting Sampling Points**

### **10.4 Photo-Documentation**

### **10.5 Sample Collection Paperwork**

10.5.1 Sample Labels

10.5.2 Chain of Custody/Sample Analysis Request

10.5.2.1 External Chain of Custody and Sample Analysis Request Form WITH shipping container.

10.5.2.2 External Chain of Custody and Sampling Analysis Request Form WITHOUT shipping container.

New Jersey Department of Environmental Protection External Chain of Custody and Sample Analysis Request Form (With Shipping Container)

New Jersey Department of Environmental Protection External Chain of Custody and Sampling Analysis Request Form (Without Shipping Container)

## **Chapter 11 – Sample Shipment**

---

### **11.1 Introduction**

### **11.2 Definitions**

### **11.3 Training**

### **11.4 Shipper's Responsibility**

### **11.5 Hazard Classes**

### **11.6 Packing**

## **11.7 Marking and Labeling**

## **11.8 Documentation**

## **11.9 Preservation of Samples Relative to Dangerous Goods Shipment**

Table 11.1 Hazard Classes and Applicable Regulations

## **References**

## **Chapter 12 – Radiological Assessment**

---

### **12.1 Introduction**

Figure 12.1 Comparison of MARSSIM and the Technical Requirements

### **12.2 The Planning Stage (Data Life Cycle)**

### **12.3 Site Identification/Historical Site Assessment**

### **12.4 The Scoping Survey**

12.4.1 Identify Contaminants

12.4.2 Establish the Derived Concentration Guideline Levels (DCGLs)

12.4.3 Classify the Area by Contamination Potential

12.4.4 Determine Background

12.4.5 Perform the Survey

12.4.6 Document the Scoping Survey Results

### **12.5 The Characterization Survey**

12.5.1 Determination of Lateral and Vertical Extent of Contamination

12.5.2 Determine Background

12.5.3 Classify the Area by Contamination Potential

12.5.4 Document the Characterization Survey Results

### **12.6 The Remedial Action Support Survey**

### **12.7 The Final Status Survey**

12.7.1 Revisit the Area Classifications

12.7.2 Determine the Relative Shift

12.7.3 Determination of Acceptable Type I and Type II Decision Errors

12.7.4 Determine the Number of Samples Needed

12.7.5 Additional Samples for Elevated Measurement Comparison in Class 1 Areas

Table 12.1 Outdoor Area Dose Factors

12.7.6 Determining Sample Locations

12.7.7 Investigation Levels and Scanning Coverage Fractions

Table 12.2 Final Status Survey Investigation Levels

12.7.8 Special Survey Considerations Subsurface Residual Radioactivity

12.7.9 Determining Compliance

12.7.10 Mixing After Demonstrating Compliance with the Pre-mixing DCGLs

12.7.11 Documenting the Final Status Survey

## **References**

## **Acronyms**

## **Glossary**

## **Endnotes**

## **Chapter 13 – Personnel Protection**

---

### **13.1 Introduction**

### **13.2 Selection of Respiratory Equipment**

13.2.1 Self-Contained Breathing Apparatus (SCBA)

13.2.2 Supplied-Air Respirators (SARs)

13.2.3 Combination SCBA/SAR

13.2.4 Air-Purifying Respirators

### **13.3 Selection of Protective Clothing and Accessories**

13.3.1 Selection of Chemical-Protective Clothing (CPC)

13.3.2 Other Considerations

13.3.3 Special Conditions

### **13.4 Selection of Ensembles/Level of Protection**

Table 13.1 Sample Protective Ensembles – Level of Protection – A

Table 13.1 Sample Protective Ensembles – Level of Protection – B

Table 13.1 Sample Protective Ensembles – Level of Protection – C

Table 13.1 Sample Protective Ensembles – Level of Protection – D

### **13.5 PPE Use**

13.5.1 Training

13.5.2 Work Mission Duration

13.5.3 Personal Use Factors

13.5.4 Donning an Ensemble

13.5.5 Respirator Fit Testing

13.5.6 Doffing an Ensemble

13.5.7 Inspection

13.5.8 Storage

### **13.6 Heat Stress and Other Physiological Factors**

13.6.1 Monitoring

13.6.2 Prevention

Table 13.2 Signs and Symptoms of Heat Stress

13.6.3 Other Factors

13.6.3.1 Physical Condition

13.6.3.2 Level of Acclimatization

13.6.3.3 Age

13.6.3.4 Weight

## **References**

## **Chapter 14 – Personnel Contamination Reduction**

---

### **14.1 Introduction**

### **14.2 Steps In Doffing Disposable PPE**

### **14.3 Doffing Reusable PPE**

Figure 14.1 Maximum Decontamination Layout Level A Protection

Figure 14.2 Maximum Decontamination Layout Level B Protection

Figure 14.3 Maximum Decontamination Layout Level C Protection

Figure 14.4 Minimum Decontamination Layout Levels A & B Protection

Figure 14.5 Minimum Decontamination Layout Level C Protection

### **14.4 Low Level Contamination**

## **References**

## **Glossary of Technical Terms**

---